


Bushnell® TRAILSCOUT™

TRAIL CAMERA
VIEWER/COPIER

Instruction
Manual



Model #: 11-9501
LIT #: 98-1006/07-07

The Bushnell® Trail Scout Viewer/Copier is a convenient, portable device that is the perfect companion for any model of Bushnell Trail Scout™ or Sentry™, as well as most other trail camera brands*. Simply remove the SD or CF card from your trail cam and place it into the slot for that type of card. The battery powered Viewer will automatically read and display the files captured by the trail camera, allowing you to easily see what your camera has captured in the field, without taking along a bulky, expensive, fragile laptop computer. Both still photos and video clips (with audio if your camera records it) may be reviewed. You can delete unwanted photos to free up more space for new shots, erase all files from the card, protect important photos from accidental erasure, and even copy all of your photos/videos (or just your favorites) to another SD card to take home with you. The Viewer has a USB port, so you can also use it as a card reader with your PC at home to view or backup your photos to a hard drive.

Trail Scout Viewer/Copier Technical Specifications

Display	2.5" TFT LCD, 480x234 pixels
USB	USB 1.1 standard, USB Mass Storage device
Software requirements	<i>(For card reader function)</i> Windows 2000, ME,XP or Vista (<i>Windows 98 not supported</i>); Mac OS9 or OSX.
Card Slots	Read only: 1 SD & 1 CF slot (<i>Camera</i>). Read or Write files: 1 SD slot (<i>Storage</i>)
Card Compatibility	Maximum card capacity:1 GB or less, Normal or High speed
File Compatibility	Standard JPEG (.jpg) still photo files, AVI (.avi) video files
Power Supply	2xAA batteries, alkaline, lithium or NiMh rechargeable (<i>>2000mAh recommended</i>)
Power Consumption	0.85 w

** Compatibility with still & video files on cards from non-Bushnell cameras cannot be assumed, due to potential differences in file directory structure and file compression standards.*

The Trail Scout Viewer/Copier Is Compatible With All Current & Future Models of Bushnell Trail Scout and Trail Sentry Cameras, Including These:

119833—Digital Trail Scout 3.0MP


Great images and scouting technology at a great value. This camera will sense deer and other game as far out as 45 feet with its passive infrared sensor. Low-battery indicator lights when battery life drops below 25%. Motion LED lights when activity is detected by the sensor in regular imaging mode and during setup mode for aiming. Weatherproof. Date/Time/Moon Phase stamp feature. Comes complete with aircraft aluminum security cable, padlock, and tree bracket. Textured “bark-like” surface for maximum concealment.

119935/119905 (RealTree AP® Camo)—Digital Trail Scout 5.0MP with Night Vision

With all the features of the 3.0MP Trail Scout plus Night Vision and laser aiming, this is the top of the line digital trail camera. Still photos are stored with 5 megapixel resolution (via software processing), and the video clips are recorded with audio captured by a built-in microphone. Choose your setting for regular camera flash or stealth-like LED flash. LED flash enables you to discretely image game in the night without a visible flash. There is no need to worry about your flash giving away your position in popular, busy hunting areas. And no need to manually set an infrared filter switch for day or night mode to get great results—it’s done for you automatically. This camera comes complete with a laser aiming beam for easy set up in the woods.

Parts Guide

Item	<i>A</i>	<i>B</i>	<i>C</i>	<i>D</i>
Function	Camera Card Slots (<i>Only Reads files</i>)	Storage Card Slot (<i>Read or Write files</i>)	USB Port	Power Switch



With the slots oriented as shown (lettering upright, USB on right), SD cards should be inserted “face down” (metal contacts on card facing up, notched corner on rear left). To insert, push it clicks. To remove SD cards, push in again, then pull out. CF cards (face up) simply push in/pull out.

Button #	<i>1-Delete</i>	<i>2-Left</i>	<i>3-Right</i>	<i>4-Copy</i>
Function in Normal Display Mode	DELETE or ZOOM	BACKWARD (Last Photo)	FORWARD (Next Photo)	COPY
Function in Delete, Copy & Setup Menus	Next Menu Item	OK (Confirm Setting)	not used	Previous Menu Item

Display Icons

Current file # / Total files on card



Resolution (in pixels)
of the Photo

Battery Indicator

DISPLAY ICONS-STILL PHOTOS

File Locked
(also a still photo option)



Indicates Video File Type

DISPLAY ICONS-VIDEO CLIPS

Setup

1. Open the battery cover located on the bottom of the Viewer by sliding it the direction of the arrow on the cover, and insert two AA size batteries (alkaline, lithium or NiMh) with the flat end (negative, or “-” terminal) of each battery in contact with the springs. Slide the cover back to the closed position. The small holes on the back of the Viewer, just below the battery cover, allow sound from the speaker to be heard during playback of video clips that may also contain audio.
2. Slide open the door on the left side of the Viewer in the direction of the arrow on the door. Insert an SD or CF card* into the correct size slot (*do not attempt to insert an SD card into the CF card slot*). With the slots oriented as shown in the **Parts Guide**, (lettering upright, USB on right), SD cards should be inserted “face down” (metal contacts on card facing up, notched corner on rear left). To insert, push the SD card in until a click is heard. To remove, push in again, then pull out. CF cards simply push in/pull out (face up). Use the “Camera” slots (A) for cards from your Trail Camera. Use the “Storage” slot (B) for a blank SD card (optional) if you will want to copy photos from a card in one of the “Camera” slots. After inserting your card(s), briefly press the **Power** switch on the lower right side of the Viewer. The screen will activate in a few seconds (the time it takes may vary with the number and size of the files on your card) and display the first image on your camera card. To turn off the Viewer when you are done, press the **Power** button again. Replace the door (cards may be left in place) that covers the slots and USB port when not using or carrying your Viewer, to prevent the entry of dust and dirt.
3. Please refer to the section titled “Setup Options” for details on how to change the language used for all display menus and change the Auto Off interval if desired.

* *Secure Digital or Compact Flash*

Viewing Photos and Videos

If only one card is inserted into any of the Viewer's card slots (only CF cards can be used in the CF slot), the Viewer will automatically display the files stored on that card. If cards are inserted into both the SD "Storage" card slot (B) and either of the "Camera" slots (A), only the files stored on the card in the "Camera" slot will be displayed. If you want to quickly check the files on the SD card in the "Storage" slot (to make sure it's a blank card or the one you intended to copy your camera's files to), you may temporarily remove the card from the "Camera" slot-the viewer will then show the photos stored on the "Storage" card. When finished, replace the "Camera" card back into its slot (the Viewer will switch back to displaying the files on that card again).

Use the **Right** and **Left** arrow buttons to step forwards or backwards through your displayed photos and/or videos. The first frame of any video files will be shown on the screen, and the lower left corner of the display will indicate "AVI", instead of the pixel resolution as it does for still photos. To play a video, press the **Copy** button. Press it again to stop video playback.

3x Zoom Display Function (*Still photos*)

Photos (but not video clips) stored on your card may be viewed at an enlarged 3x magnification. This "zoom" feature allows you to better identify a small object in a photo, read a date imprint more easily, or check the photo quality. To use the zoom function, press and hold the **Delete** button for a few seconds until the display shows the enlarged center area of the photo, along with 4 small yellow arrows. To scroll around and see other sections of the photo at this 3x magnification, briefly press (tap) the **Left** and **Right** arrow buttons to move the to left or right areas of the photo. Press the **Delete** or **Copy** buttons to move the view down or up. When finished using the zoom function, press and hold the **Delete** button again to return the normal image.

Deleting Photos/Videos

To delete the one or more photo or video files from the card, briefly press the **Delete** button. You will see this list of options (the Delete Menu):

DELETE ONE
DELETE ALL
LOCK
UNLOCK
EXIT

To delete the currently displayed photo from its card, leave “DELETE ONE” highlighted (or press the **Delete** or **Copy** buttons to select it if necessary). Press the **Left** button-you will see “DELETE ONE “ with a choice of “YES” or “NO” (“NO” is the highlighted default, to prevent accidental erasure). To delete the selected photo (still visible on the display underneath), press the **Copy** button to select “YES”, then press the **Left** button to confirm. The display will indicate “DELETING FILE” as the photo is erased, then return to the normal display of the previous photo.

To delete multiple photos, either select the next photo with the **Right/Left** buttons and repeat the above procedure, or highlight “DELETE ALL” on the Delete Menu list of options (press **Delete** to move down the menu list), and repeat the same process used for deleting a single file (press the **Left** button, select “Yes” and press **Left** again). The display will indicate “ DELETING FILES” then return to the normal display of the previous photo.

Lock/Unlock Feature (Protecting Files)

To protect the currently displayed photo/video from being accidentally deleted or erased, briefly press the **Delete** button to view the Delete Menu. Press the **Delete** button to move down the list until “LOCK” is highlighted, then press the **Left** button to confirm. The display will indicate “LOCKED” then return to the normal view. A padlock icon will now be visible in the top right corner whenever this photo or video file is displayed on the Viewer. This means that the DELETE (ONE or ALL) function will not be able to affect the protected file, and it will remain on the card (until it is “unlocked” and deleted). To unlock or remove the delete protection from currently displayed file, select “UNLOCK” from the Delete Menu and press the **Left** button to confirm. The padlock icon will be removed, and the photo can be erased now if desired. The “Lock” feature can be very useful if you only have two photos you want to keep that are stored on a card along with a large number of other photos that aren’t any good and you wish to erase over. Simply “lock” the two good photos, then use the DELETE ALL function. All photos except the two locked ones will be quickly deleted-much faster than deleting 48 out of 50 total photos, one at a time!

Copying Photos To A Second Card (Camera Slot > Storage Slot)

The Viewer will also allow you to copy your photos from your camera’s card to a new SD card. This is a very convenient way to take your trail camera pictures home with you to view, print, etc on a PC, while returning the original card to the trail camera to capture another round of photos. To do this, remove the card from the camera, copy its contents to a new SD card you have inserted in the “Storage” slot (B), then you can delete all the photos from the original card and put it back in your camera. If you are using multiple trail cameras to cover a large area, you can “make the rounds” and repeat this process for all of them-just be sure to purchase a “storage” card with enough capacity to hold all of the copied files. For example, if you plan to copy all contents from three 32MB “camera” cards, use a 128MB or greater “storage” card so it will hold the total contents of all three cards (96MB) if they are full.

Copying Photos To A Second Card-*cont.*

To perform the copy process, a blank SD card (or one previously used to copy files with the Viewer) should be inserted in the “Storage” slot located below the CF card slot. You may use standard or high speed SD cards, with any capacity up to a maximum of 1GB.

To copy one or all of the photo files from the card in a “Camera” slot to the SD card in the “Storage” slot, hold down the **Copy** button until you see the Copy Menu:

COPY ONE
COPY ALL
EXIT

The Copy Menu works the same way as the Delete Menu-press the **Delete** or **Copy** buttons to select (highlight) an option, and press the **Left** button to confirm or perform an action.

Select COPY ONE (to copy only the currently displayed photo/video) or COPY ALL (to copy all files stored on a “Camera” slot card to the “Storage” slot SD card) from the Copy Menu options.

Next, press the **Left** button. During the file copying process, the display indicates “Copy to Card”, with “Please Wait” flashing below (larger files such as high resolution photos or long videos will take longer to copy). The name of the file being copied is also displayed at the bottom of the screen. When the copy process is completed, the display will indicate “End Copy File” and return to the normal view screen. If you have more files on other cards to copy to the Storage card, simply remove the first Camera card, insert the next one, and repeat the Copy process.

Note: Do not turn off the Viewer or remove any card during the copy process, to prevent possible damage to the card or your files.

Setup Options

Hold down the **Left** button for a few seconds to view the Setup Menu. Just as in the other menus, use the **Delete** and **Copy** buttons to select (highlight) “**LANGUAGE**” or “**AUTO OFF**” from the Setup Menu, then press the **Left** button briefly (don’t hold it down) to see the available settings for that option. Press **Delete** or **Copy** again to select your preferred setting, then press the **Left** button to confirm the setting and return to the Setup options. When finished, select “**EXIT**” and press the **Left** button to return to the normal display. The Setup options function as follows:

LANGUAGE: Selects your preferred language for all display menus/messages. English (default), French, German, Italian and Spanish are available.

AUTO OFF: Select 1 MIN, 2 MIN (default), or DISABLE. This determines the length of time before the Viewer will automatically shut off to save battery power, after the last time any button has been pushed. If you select “DISABLE”, the viewer will not shut off until you press the **Power** button. Selecting 1 MIN or 2 MIN will help extend battery life if you forget to turn off the viewer or if the **Power** button is accidentally activated while transporting the Viewer, as it will limit the time the Viewer remains on when it is inactive.

Using the Viewer With A Computer (Card Reader Function)

The USB port next to the card slots on the left side of the Viewer allows it to function as an SD “card reader” when connected with the included USB cable to any computer (Windows 2000, ME, XP or Vista (Windows 98/98SE is not supported); Mac OS 9 or OS X). The connected Viewer will operate just like an external hard drive, from which your photos may be accessed for viewing, editing and/or storing on your computer.

Transferring Photos to Your PC - Step by Step

1. Make sure the Viewer power is on first, then connect the supplied cable to the Viewer’s USB port (open the door on the left side of the Viewer), then directly to a main USB port on your computer-do not use front panel/keyboard USB ports or unpowered “hubs”.
2. The LCD display will indicate that the Viewer has been recognized as a standard “Mass Storage” device. This means that the camera files can be easily viewed, edited, or copied to your hard drive, just as if they were stored on an external hard drive or CD-ROM. (Mac users: the Viewer will be seen as a new drive icon on your desktop.) Note: if you connect the Viewer to your PC first, then turn its power on, the Viewer may be incorrectly identified by your computer as a new or unknown “PC Camera” (webcam). If so, simply click “Cancel” on your PC, disconnect the Viewer and try it again, this time powering on the Viewer before connecting the USB cable. If the Viewer “locks up” or does not respond, slide open the battery compartment door and temporarily pull one of the batteries out, re-insert it and try again.

Transferring Photos to Your PC-*cont.*

3. (This step is not required with Windows XP or Vista-you may simply use the options that will appear on your PC after the Viewer is connected to view, copy, edit, email, etc. your photos). Open “My Computer” or Windows Explorer. The Viewer will be shown as a new “Removable Disk” with an unused drive letter assigned to it. Double click this new “Disk” icon, then open any folder or folders found inside to get to your photo files. Single clicking any file should show a small preview image.

4. Click “Edit>Select All” (or click on one photo, **ctrl**+click to select multiple photos), then “Edit>Copy to Folder” (in Windows menus). Select an existing folder on your hard drive, such as “My Pictures”, or create a new folder (e.g., “Trail Cam #2-Maine-May 07”), then click “OK” to transfer copies of the photo files you want.

5. After the photos are transferred to your hard drive, you can disconnect the Viewer. Windows 2000 may produce a screen warning that you have disconnected a USB device without stopping or ejecting the “disk” first (your photo files will not be harmed). If so, check the box that adds an icon to your system tray or taskbar. Then next time you finish transferring photos, you can click that icon first, and “Stop the USB Mass Storage Device” before disconnecting the Viewer. On Macs, you should “eject” the Viewer before disconnecting, as you would any external storage device.

6. You’re now ready to open the photo files in any photo editing software. Just use **File>Open** and go to the folder where you stored the photos earlier. It is also possible to open and work with your photos directly from the Viewer while it is still connected-under “**File>Open**”, select the “Removable Disk”, and open the folders inside until you get to the JPEG photo files. If you choose to work this way, from a connected Viewer, be sure that you save the photo (when you are done editing) to your hard drive, and not the Viewer’s “Camera”/Source card.

Transferring Photos to Your PC*-cont.*

7. If you are using photo editing software on your computer, refer to the manufacturer's manual or Help menu for details on using its features. Along with adjusting the brightness, contrast, sharpness and color of your photos, you can resize the photo to fit the paper if you are printing, or save a smaller, low or medium resolution version for email or inserting into documents. When you are ready to save your edited .jpg file to your hard drive, you may want to use "Save As" and give it a more descriptive name than "SUNP00003". Doing this also preserves the original file as a backup if you decide to use it for something different later (for example, it's hard to make a good large print from a photo file that's been reduced in size for email). Make sure you have successfully transferred all the photos you wanted to save before using "Delete All" on your camera source card to make room for new images.

TWO-Year LIMITED WARRANTY

Your Bushnell® product is warranted to be free of defects in materials and workmanship for two years after the date of purchase. In the event of a defect under this warranty, we will, at our option, repair or replace the product, provided that you return the product postage prepaid. This warranty does not cover damages caused by misuse, improper handling, installation, or maintenance provided by someone other than a Bushnell Authorized Service Department.

Any return made under this warranty must be accompanied by the items listed below:

- 1) A check/money order in the amount of \$10.00 to cover the cost of postage and handling
- 2) Name and address for product return
- 3) An explanation of the defect
- 4) Proof of Date Purchased
- 5) Product should be well packed in a sturdy outside shipping carton, to prevent damage in transit, with return postage prepaid to the address listed below:

IN U.S.A. Send To:

Bushnell Outdoor Products
Attn.: Repairs
8500 Marshall Drive
Lenexa, Kansas 66214

IN CANADA Send To:

Bushnell Outdoor Products
Attn.: Repairs
25A East Pearce Street, Unit 1
Richmond Hill, Ontario L4B 2M9

For products purchased outside the United States or Canada please contact your local dealer for applicable warranty information. In Europe you may also contact Bushnell at:

BUSHNELL Performance Optics GmbH
European Service Centre
MORSESTRASSE 4
D- 50769 KÖLN
GERMANY
Tél: +49 (0) 221 709 939 3
Fax: +49 (0) 221 709 939 8

This warranty gives you specific legal rights.
You may have other rights which vary from country to country.
©2007 Bushnell Outdoor Products

FCC Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Shielded interface cable must be used with the equipment in order to comply with the limits for a digital device pursuant to Subpart B of Part 15 of FCC Rules.

Specifications and designs are subject to change without any notice or obligation on the part of the manufacturer.





For further questions or additional information please contact:

Bushnell Outdoor Products

9200 Cody, Overland Park, Kansas 66214

Customer Service (800) 423-3537 • www.bushnell.com

©2007 Bushnell Outdoor Products